

4230 Series




HELPLINE 1-800-282-2886


8 a.m. to 7:30 p.m. (CST), Monday - Friday 10 a.m. to 6:30 p.m. (CST), Saturday - Sunday

www.eureka.com



## Vhat's in the carton






OWNER'S






Use a Phillips screwdriver.


## Easy assembly





Vacuum body

Slide upper housing onto vacuum body. Fasten with 2 medium screws (A).




Dust cup


Insert handle until mark aligns with top of housing Fasten with 1 long screw (B).



Slide tool caddy onto housing. Sides will click into position.




Press firmly to snap hose retainer onto back of vacuum body.




Position hose connector on back of vacuum. Fasten with 1 short screw (C).



Pull out bottom of hose retainer and position hose.




Place hose over hook on handle. Secure in sides of tool caddy.




Push end of wand into wand retainer on side of vacuum.



Place dust cup on body and snap into place.



Place dusting brush and crevice tool on tool caddy.




Pull up plug and slip into slot on tool caddy.




Snap Power Paw® into clip on front.




## Get ready to vacuum




Push down release button and pull out handle to desired height.




Pull out full length of cord; push into cord retainer.




Step on power switch to turn on; step on again to turn off.



Step on handle release to lower handle into position.




If vacuum is hard to push, use foot to raise carpet setting.



For accessories: Loosen end of wand, pull out and attach tool.



Press button to rewind cord.



Lift latch to remove dust cup. Empty after each use.

PROBLEM SOLVING Refer to Owner's Guide.

MAINTENANCE SCHEDULE Refer to back of dust cup or Owner's Guide.